



Comfort Zone™ is a blanket, towel, and robe warming system.

CAUTION: To avoid risk of electric shock or fire, keep all liquids or flammable fluids out of unit.

CAUTION: Interior of Comfort Zone™ is electrically heated. Hot metal plates inside unit could burn skin or melt plastic. DO NOT place items which have plastic or metal components inside unit.

DO NOT try to disassemble, modify, or repair Comfort Zone™. There are no user-serviceable parts. Contact Life Gear if you have any problems with the unit.

For safety and to extend the life of the product, turn off and unplug Comfort Zone™ when not in use.

INSTRUCTIONS FOR USE

1. Remove cord and blankets, towels, or robes from interior of Comfort Zone™.
2. Remove blankets, towels, or robes from plastic. Wash blankets, towels, or robes before first use.
3. Securely plug cord into Comfort Zone™ and outlet.
4. Place blankets, towels, or robes in Comfort Zone™.
5. Close the Comfort Zone™ and securely close fasteners on front of unit. Comfort Zone™ automatically shuts off if unit is open.
6. Push red switch on side of Comfort Zone™. Light will turn on, showing that unit is receiving power.
7. If Comfort Zone™ is cold, two blankets, two towels, or two robes will heat to maximum temperature in approximately 20 minutes, depending on environmental conditions. If Comfort Zone™ is already warm, heating time will be shorter.
8. For fastest heating, use only one blanket, towel, or robe. Leave blanket, towel, or robe in Comfort Zone™ for 5 minutes. Remove blanket, towel, or robe and refold to expose un-heated portions. Place blanket, towel, or robe back in Comfort Zone™ for 5 minutes to complete heating.
9. After use, push red switch on side of Comfort Zone™ to turn unit off (light will turn off).

CLEANING

1. Turn off and unplug unit and allow to cool completely.
2. Wipe interior and exterior of unit with dry or damp cloth.
3. Allow unit to dry completely before next use.